










A	B	C	D	E	F	G	H	I
								
x4	x4	x1	x1	x1	x4	x4	3mm/4mm x1	x1


EN Also required
FR Également requis
DE Ebenfalls benötigt
ES También se requiere




Pozi-drive




7



8



9



- A** Plastic Wall Plug
(8mm Fixing Hole 40mm Long)
- B** 5mm x 50 Long Fully Threaded
Pan Headed Pozi Drive Screw
- C** Safety / Security Cable
- D** M5 Flat Washer
- E** M5 10mm Button Head
Hex Drive Screw / Bolt
- F** M5 x 12mm
Countersunk Head
Hex-drive Screw / Bolt
- G** M6 x 20mm
Countersunk Head
Hex-drive Screw / Bolt
- H** 3mm / 4mm Hex Key
Wrench
- I** Velcro Tape

EN Inverted Speaker mounting**FR** Fixation inversée de l'enceinte**DE** Umgedrehte Lautsprechermontage**ES** Montaje de altavoz invertido